Diagram 6 Fuel Pump